



ACCESSORIES

MUST BE ORDERED SEPARATELY - NOT FURNISHED WITH COMPLETE CONTACTOR

A   AUXILIARY CONTACTS	M   MECHANICAL INTERLOCK KIT	T   TIE BAR KIT
SINGLE (1 N.O. & 1 N.C.) PART NO. 68011-008 DOUBLE (2 N.O. & 2 N.C.) PART NO. 68011-009	PART NO. 68041-004 FOR STANDARD 6,625" CONTACTOR SPACING	PART NO. 59400-005 FOR STANDARD 6,625" (NOT AVAILABLE FOR MAGNETIC DISCONNECT)
INCLUDES OPERATING STRIKER & MFG. HARDWARE REPAIR PARTS ON B-68011 Pg. 1.	REPAIR PARTS ON A-58671	REPAIR PARTS ON A-59400 Pg. 1

NOTES

- (1) COMPLETE CONTACTOR AVAILABLE WITHOUT MOUNTING PAN.
- (2) INCLUDES SUPPORT BOSS

TABLE 1 OPERATING COIL

VOLTS	PART NUMBER	OHMS	COLD
275	67890-001	1080	
230/250	67890-002	900	
119/125	67890-003	225	
75	67890-004	82	
57.5	67890-005	49	
24	67890-006	8.6	
36	67890-007	19	
12	67890-008	2.22	

ITEM	DESCRIPTION	NOTES	PART NO.	QTY.
1	BASE		68022-001	1
2	MOUNTING FOOT		68023-000	1
3	STATIONARY CONTACT BRACKET		58718-000	1
4	CONTACT TIP (COPPER)		18402-000	1
5	CONTACT TIP (SILVER FACED)		18402-001	2
6	BLOWOUT COIL		41171-001	1
7	BLOWOUT COIL SPACER		66870-031	1
8	BLOWOUT GUARD ASSEMBLY		68030-000	1
9	D.C. BLOWOUT CORE (SOLID)		66870-033	1
10	A.C. BLOWOUT CORE (SLOTTED)		18599-000	1
11	BLOWOUT INSULATING TUBE		18601-000	1
12	BLOWOUT INSULATING WASHER		18603-000	2
13	UPPER TERMINAL ASSEMBLY		68026-000	1
14	FLUX PLATE ASSEMBLY - LEFT HAND	(2)	18061-000	1
15	FLUX PLATE ASSEMBLY - RIGHT HAND	(2)	18062-000	1
16	ARC SHIELD ASSEMBLY		18063-000	1
17	ARC SHIELD RETAINER		59653-100	1
18	STATOR ASSEMBLY		19681-000	1
19	OPERATING COIL	SEE TABLE 1	58720-001	1
20	COIL CORE		18253-000	1
21	CORE CAP		18657-000	1
22	ARMATURE ASSEMBLY		18049-000	1
23	SHUNT HOLDING BEARING PIN		41728-000	1
24	SHUNT SPRING		41719-000	1
25	CONTACT FINGER (SILVER FACED)		41719-001	1
26	CONTACT FINGER (COPPER)		41719-002	1
27	FINGER SHUNT		68027-002	1
28	LOWER CONNECTING BUS		68024-001	1
29	CONTACT SPRING		41734-000	1
30	FINGER SPRING RETAINER ASSEMBLY		68048-000	1
31	SPRING RETAINER HINGE PIN		41733-000	1
32	COTTER PIN		57402-006	2
33	10-24 X 5/8 LG ROUND HEAD SCREW		47241-127	1
34	#10 SPRING LOCKWASHER		47252-036	1
35	NON-MAGNETIC SPRACER		47253-016	1
36	1/4-20 X 1 1/2 HEX HEAD SCREW		47246-069	1
37	1/4-20 X 1 1/2 HEX HEAD SCREW		47252-039	1
38	1/4-20 X 1 1/2 HEX HEAD SCREW		47252-038	1
39	5/16-18 X 3/4 HEX HEAD SCREW		47246-079	1
40	5/16-18 X 1 STAINLESS STEEL SCREW		47779-081	1
41	5/16-18 X 1 1/2 STAINLESS STEEL SCREW		47779-083	1
42	5/16-18 X 3 1/2 HEX HEAD SCREW		47246-101	1
43	5/16 SPRING LOCKWASHER		47252-039	8
44	5/16-18 NUT		47253-002	3
45	5/16 INTERNAL STAR LOCKWASHER		47304-010	1
46	3/8-16 X 3/4 SLOTTED FLUSTER HEAD CAP SCR		48624-334	1
47	3/8-16 X 3/4 HEX HEAD SCREW		47246-102	3
48	3/8-16 X 1 1/4 HEX HEAD SCREW		47246-103	1
49	3/8-16 X 1 1/4 HEX HEAD SCREW		47246-104	4
50	3/8 WASHER STEEL		47250-020	6
51	3/8 SPRING LOCKWASHER		47252-040	7
52	3/8-16 NUT JAM		47253-603	4
53	STUD 1/2 - 13 X 1 15/16		68475-021	1
54	PAN ASSEMBLY	(1)	68038-000	1
55	5/16-18 X 1 HEX HEAD SCREW		47246-081	3
56	5/16-18 STEEL FLAT WASHER		47250-297	3

REV	DATE	BY	DESCRIPTION
K			
I	9-30-99	KRE	REDRAWN TO CAD
H	9-27-99	RR	ALX WAS 68040
G	11-29-93	WSM	REMOVED ITEM 44, 1/4 FLATWASHER
F	7-30-92	DND	ECN 5210-186
E			
D			
C			
B			
A			

  

REV	DATE	BY	DESCRIPTION
E	6-9-91	BS	ECN 5210-109
D	6-13-93	FB	ITEM 7 WAS 68022, REMOVED ITEM 48
C	12-11-92	RR/BS	ITEM 63 WAS QTY 2
B	6-9-91	FB	WAS P/N 18599
A	12-8-90	FB	REMOVED BAZED COIL

  

LINEAR	HOLE	ANGLES	REPAIR PARTS BULL. 5110 & 5210
0.X ±.000	0.002	0.002	NEMA SIZE 5A, 400 AMP CONTACTOR
0.0XX ±.000	0.001	0.001	MOLDED BASE & WELDED ARMATURE
0.0XX ±.000	0.001	0.001	
0.0XX ±.000	0.001	0.001	

  

DATE	BY	DR	CHK	REF.
8-21-90	DR	DR	OK	

Hubbell Industrial Controls, Inc. DRG. NO. RP-C-59355-1 OF 1