



ITEM	DESCRIPTION	PART NO.	QTY.
58	.250-.20 X 2.00 LG. HEX HEAD SCREW	47246-071	2
59	ARC SHIELD ASSEMBLY	16973-000	1
60	ARC SHIELD ASSEMBLY	16973-000	1
61	AUXILIARY CONTACT ASSEMBLY	SEE TABLE	1
62	.250 S.S. SPLIT LOCK WASHER	47252-238	3
63	.312 FLAT WASHER	47250-505	1
64	ARC SHIELD RETAINER	68323-001	1
65	SPADE TERMINAL #8	57513-066	1

ITEM	DESCRIPTION	PART NO.	QTY.
48	.250-.20 X 1.00 LG. S.S. HEX HEAD SCREW	47278-066	2
50	.250-.20 X 2.50 LG. HEX HEAD SCREW	47246-073	1
51	.312-18 X .75 LG. HEX HEAD SCREW	47246-079	1
52	.250-.20 HEX NUT	47253-601	2
53	.250 FLAT WASHER	47250-502	4
54	.312 INTERNAL TOOTH LOCK WASHER	47304-010	4
55	STANDOFF SPACER	57690-000	2
56	.250-.20 BRASS HEX NUT	47254-011	1
57	.250 EXTERNAL TOOTH LOCK WASHER	47303-008	3

NOTE: SEE THIS RPC AFTER NOVEMBER 2000. SEE RPC-58867-2 BEFORE NOVEMBER 2000

REMOVAL PARTS BULLETIN 5210
FIBERGLASS BASE 100 AMP ONE POLE
NORMALLY CLOSED DC CONTACTOR - SIZE 3
MODEL 2000

ITEM	DESCRIPTION	PART NO.	QTY.
1	BASE ASSEMBLY	58866-002	1
2			
3	STATOR ASSEMBLY	16979-000	1
4	ARMATURE ASSEMBLY	19797-000	1
5	ARMATURE HINGE PIN	58843-001	1
6	#10-24 X .62 LG. PAN HEAD SCREW	49137-076	1
7			
8	SPRING ADJUSTMENT SCREW	42899-000	1
9			
10			
11	.312-24 HEX NUT	47253-204	1
12			
13	CONTACT HOLDER ARM	16927-000	1
14	CONTACT TIP	16924-000	2
15	ARC HORN	68056-001	1
16	.250 SPLIT LOCK WASHER	47252-038	4
17	FINGER SPRING	16960-000	1
18	MOVABLE CONTACT HINGE PIN	16966-000	1
19	FINGER SPRING	16966-000	1
20	FINGER SHUNT CONTACT HINGE PIN	16966-000	1
21	.250 X 1.00 LG. FILLISTER HEAD SCREW	47244-150	1
22			
23	.250-.20 HEX NUT	47253-601	1
24	OPERATING COIL CORE	58672-001	1
25	OPERATING COIL CORE	58672-001	1
26	OPERATING COIL CORE	58665-001	1
27	OPERATING CORE CAP	42840-000	1
28	.312-18 X .75 FILLISTER HEAD SCREW	48624-307	1
29	OPERATING SPRING	19257-000	1
30	LOCKOUT COIL CORE	57585-004	1
31			
32	.312 BRASS FLAT WASHER	47251-012	6
33	.312-18 BRASS HEX NUT	47254-013	6
34			
35	.312-18 X 1.75 LG. BRASS STUD	57438-042	2
36			
37	14 GA. Q-1251 WIRE 6.00 LONG	801-14-08-14	1
38	BLOWOUT COIL MOUNTING BASE	58667-001	1
39	STATIONARY CONTACT BRACKET	58665-001	1
40	BLOWOUT COIL - 230V 58860-001	SEE TABLE	1
41	BLOWOUT COIL - 550V 58860-004	SEE TABLE	1
42	BLOWOUT COIL SPACER	16921-000	1
43	BLOWOUT GUARD	66870-033	1
44	BLOWOUT CORE INSULATOR	16962-000	1
45	BLOWOUT COIL INSULATING WASHER	16961-000	2
46	L.H. FLUX PLATE ASSEMBLY	16966-000	1
47	R.H. FLUX PLATE ASSEMBLY	16964-000	1
48	TERMINAL	58861-001	1
49	.250-.20 X 1.00 LG. S.S. HEX HEAD SCREW	47278-066	2
50	.250-.20 X 2.50 LG. HEX HEAD SCREW	47246-073	1
51	.312-18 X .75 LG. HEX HEAD SCREW	47246-079	1
52	.250-.20 HEX NUT	47253-601	2
53	.250 FLAT WASHER	47250-502	4
54	.312 INTERNAL TOOTH LOCK WASHER	47304-010	4
55	STANDOFF SPACER	57690-000	2
56	.250-.20 BRASS HEX NUT	47254-011	1
57	.250 EXTERNAL TOOTH LOCK WASHER	47303-008	3

NOTE: WHEN ORDERING REPAIR PARTS BE SURE TO FURNISH SERIAL NUMBER & PIPE NUMBER WHICH ARE LOCATED ON NAME PLATE. ALSO PART NAME & PART NUMBER.

ITEM 26 OPERATING COIL	OPERATING VOLTAGE	OPERATING COIL P/N
CONTRACTOR F/N	230/250V	68091-001
58867-010	115/125V	68091-002
58867-012	230/250V	68091-001
58867-013	115/125V	68091-002
58867-014	230/250V	68091-001
58867-015	24V	68091-003

ITEM 40 BLOWOUT COIL	COIL P/N
CONTRACTOR ASSEMBLY P/N	58860-001
58867-010 THRU -012, -015	
58867-013, -014	58860-004

REV	DATE	BY	DESCRIPTION
A			
B			
C			
D			
E			

DRG. NO. **RPC-58867-4**

1 OF 1

RENEWAL PARTS BULLETIN 5210
FIBERGLASS BASE 100 AMP ONE POLE
NORMALLY CLOSED DC CONTACTOR - SIZE 3
MODEL 2000

DATE: 10-27-00 DR. T. JOHNSON CK.

DRG. NO. **RPC-58867-4**